



The detail pieces need to be blackened on the backs.



It goes without saying, you need to score the parts before cutting them out. Edge before gluing.



I should have done it before this, but the edges of the footplate need to be blackened on the back, also. Pre-shaping and dry-fitting are very helpful. Note: on the back end-piece, the upper 'wings' are valley folded and act as the tabs on the back of the boiler box.